

USER MANUAL

USER MANUAL | USER MANUAL | BENUTZERHANDBUCH

WIFI

Initial premises

Operational guidelines.Please take the simple guidelines instructions below as a reference.

operation Steps	operation Elements	New account	Reinstall the APP (recorded before)
Step 1	Download and Install the application	YES	YES
Step 2	Activate APP	YES	YES
Step 3	Registration Account	YES	NO
Step 4	Login	YES	YES
Step 5	Add device to control	YES	The registered device will remain.

Note:

If you have registered your account and added your device previously, when you reinstall the app and log in, the previously added device will remain.

FCC Attention (FCC ID: 2AJCLTWAC-TYWFS)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received, including interference that may cause an unwanted operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The separation between the user and the device should not be less than 20 cm.

CONTENTS

Wi-Fi module specifications and basic information.....	1
Download and install the app	2
Activate APP	3
Registration.....	4
Login.....	6
Add Device.....	8
Checking the air conditioner	10
Accounting Management.....	28
Troubleshooting.....	30

Wi-Fi module specifications and basic information

1.Minimum specifications for a smartphone:


Android version 5.0 or later IOS version 9.0 or later

2.Basic parameters for the Wi-Fi module

Parameters	Details
Network frequency	2.400 - 2.500 GHz
WLAN standards	IEEE 802.11 b/g/n (channels 1-14)
Protocol stack support	IPv4/IPv6/TCP/UDP/HTTPS/TLS/MulticastDNS
Security Support	WEP/WPA/WPA2/AES128
Network type support	STA/AP/STA+AP

3. Location and appearance of the Wi-Fi module in the indoor unit

Open the front panel, the Wi-Fi module is near the electrical box cover or on the panel.



Download and install the app



SmartLife-SmartHome

For Android smartphones

Method 1: Scan the QR code, download and install the APP.

Method 2: Open the Google Play Store on your smartphone and search for "SmartLife-SmartHome", download and install the APP.



For iOS smartphones

Method 1: Scan the QR code and follow the prompts to access the "App Store", download and install the app. Method 2:

Open the Apple "App Store" on your smartphone and search for "SmartLife-SmartHome", download and install the app.



Note:

Please enable Storage/Location/Camera permissions for this APP during installation.

Otherwise it will have some problems during operation.

Activate APP


The first time you use the app, you will need to activate it.1. Start the "SmartLife-SmartHome" APP on your smartphone.



SmartLife-SmartHome

Method 1: Tap the "Scan" button and scan the Activate QR code

Method 2: Tap "or enter activation code" at the bottom of the screen, then enter the activation code and tap "CONFIRM".



or enter the activation code

CANCELCONFIRM



Activate QR code and activation code




Note Without the QR code or activation code, you can't activate the APP and use it, keep them safe.

Registration

1. If you don't have an account, tap the "Register" button.
2. Read the Privacy Policy and tap "I Accept."




3. Tap ">" and choose your country.
4. Enter your email address.
5. Tap the "Get Verification Code" button.



Enter your email address here

Search for the country or swipe the screen up/down to find and choose the country.



Registration

- 6.Enter the verification code received by email.
- 7.Set your password with 6-20 characters including letters and numbers.
- 8.Tap "Done".

<

Enter verification code

code

* * * * *

The verification code is sent to your email:
* * * * * @****, Postpone (55s)



<

Set password

* * * * *

6-20 characters for the password, including characters, numbers

Done



Login

- 1. Tap "Sign in with an existing account." Enter
- 2. your registered account and password.
- 3. Tap the "Sign In" button.

Register

Log in with an existing account



<

Login

* * * * *

Enter your account (email) here

* * * * *

enter your password

Sign in

Forgot your password?

Login means you agree with the [Agreement with the user](#) and [Privacy Policy](#)






Login

The first time you use the APP, you need to Create Family:

- 4.Tap "Create Family".
- 5.Make a name for the family.
- 6.Set the position.
- 7.Choose from predefined rooms or add new rooms.
- 8.Tap "Done" and "Completed".



Choose the recommended room or create a new room, then tap Done.



Note:
The app can open the map on your phone and you can set your location.

Login

You forgot your password

If you have forgotten your password or want to reset your password, please follow these steps:

- 1. Tap "Forgot Password".
- 2. Enter your account (email address) and tap the "Get Verification Code" button.
- 3. Enter the verification code received in your email.
- 4. Set your new password and tap the "Done" button.

<

Login

***** >

E-mail address

Password

Access

Forgot your password?

Login means you agree with the [Agreement with the user](#) and and [Privacy Policy](#)

<

Forgot your password?

***** >

***** X

Get the verification code

<

Enter verification code

The verification code is sent to your email: ***** , Resend (55s)

<

Set password







6-20 characters for the password, including characters, numbers

Done

There are 2 modes CF (Quick Connect) and AP (Access Point) for adding device.

CF Mode



1. Turn on the indoor unit, no need to start the air conditioner.
 2. Click the "+" in the upper right corner of the Home screen or tap "Add Device" in the room that has no devices.
 3. Tap the "Split Air Conditioner" logo.
 4. Enter the Wi-Fi password that is the same as the one of your connected smartphone, then tap "Next".
 5. Follow the prompts on the next screen to reset the Wi-Fi module, then select "Confirm device reset" and tap "Next."
 6. You can see the percentage of the connection process, at the same time PP", "SA", "AP" shining in turn on the internal display.
- "PP" means "Searching the router" "SA" means "connected to the router" "AP" means "connected to the server"



There are 2 methods to add the device.

Mode 2-AP


1. Turn on the indoor unit, no need to start the air conditioner.
2. Click the "+" in the upper right corner of the Home screen or tap "Add Device" in the room that has no devices.
3. Tap the "Split Air Conditioner" logo.
4. Enter the Wi-Fi password that is the same as the one of your connected smartphone, then tap "Next".
5. Tap on the top right corner and choose "AP Mode"
Then follow the on-screen prompts to reset the Wi-Fi module, then select "Confirm device reset" and tap "Next".
6. Read the instructions carefully and tap "Connect Now".
7. On the network settings screen, select "SmartLife_****" and tap "<".
8. You can see the percentage of the connection process, at the same time "PP", "SA", "AP" lights up in turn on the internal display.
"PP" means "Searching the router" "SA" means "connected to the router" "AP" means "connected to the server"



Air conditioner control


The device control screen will appear automatically after adding the device.

The device control screen will be displayed manually by tapping the device name on the home screen.




Note:

There are two different control methods based on different software or firmware versions of the Wi-Fi module. Please read the manual carefully based on the actual control interface.




The main control interface




inpost mode

1. Tap Mode to bring up the Mode screen.
2. Select one of the Feel/Cool/Heat/Dry/Fan modes.
3. Touch anywhere around the set temperature to cancel the mode setting.



select the fan speed

1. Tap Fan to bring up the Fan screen.
2. Select one of the fan speeds High/Medium/Low/Auto.
3. Touch anywhere around the set temperature to cancel the selection.





Setting the function

- 1.Tap Function to bring up the Function screen.
- 2.Select one of the Sleep/Turbo/ECO functions.
- 3.Select SU-GIU/LEFT-RIGHT for automatic swing with UP-DOWN directionU/LEFT-RIGHT.
- 4.Touch anywhere around the set temperature to cancel the function setting.




TOtimer added

- 1.Tap Timer to bring up the Add Timer screen.
- 2.Tap Add Timer.




Adding timer

- 3.Select time, select repeat days and Timer on/off.
- 4.Select Mode/Fan Speed/Function and select the setting temperature for Timer on.
- 5.Tap Save to add the timer.




Timer Management

- 1.Tap the timer bar to edit the timer as in the process of adding the timer.
- 2.Click the switch to enable or disable the timer.
- 3.Press and hold the timer bar for about 3 seconds and the Remove Timer screen will appear, tap CONFIRM and remove the timer.





The main control interface



Air conditioner control

Setting mode



- 1.Tap the Mode button.
- 2.There are 5 modes in the Mode screen, touch one button to set the air conditioner's working mode.
- 3.Tap the X button to return to the main control screen.
- 4.The mode and wallpaper will change on the screen.



*Note:*Please read the details of each modality in the user manual for more comfortable control.

sfan speed selection

- 1.Tap the Fan Speed button.
- 2.Select the desired fan speed and tap it.
- 3.Tap the X button to return to the main control screen.
- 4.The selected fan speed indicator will appear on the screen.



Mode	Fan speed
cooling	All speeds
ventilation	All speeds
dehumidifier	
Warm up.	All speeds
Car	All speeds

Note:
The fan speed can't be set to Dry mode.

*Note:*The fan speed screen may look slightly different, Depending on the air conditioner model. Example:




Air conditioner control


Cairflow control

- 1.Tap the Precision Airflow button or the Oscillating Airflow button.
- 2.Select the airflow you want and tap it.
- 3.Tap the X button to return to the main control screen.
- 4.The selected airflow indicator will appear on the screen.

Note:For some models without automatic left-to-right wind, if you activate it, you will hear a beep, but no action.



Note:The main control screen and the airflow screen may appear slightly different, depending on of the air conditioner model. Example below:



FECO anointing

- 1.For Eco function, just touch the button to activate the function, the button will light up and the indicator will appear on the screen.
- 2.Tap again to disable the function.
- 3. Temperature controlled for some models of air conditioners: in

cooling mode, the new set temperature will be

$\geq 26\text{ }^{\circ}\text{C}.$

In heating mode, the new set temperature will be

$\leq 25\text{ }^{\circ}\text{C}.$



Mode	ECO enabled
Cool.	Yes
Ventilation	
Dehumidifier	
Heating.	Yes
Car	

ECO is disabled in Fan/Dry/Auto mode.

Note:The main control screen and ECO control method may appear slightly different depending on the air conditioner model. Example below:





Note:
ECO is also disabled in Turbo/Sleep mode for some air conditioner models.

Air conditioner control

Sleep function



- 1.Tap the Sleep button.
- 2.Select the desired sleep mode and tap it.
- 3.Tap the X button to return to the main control screen.
- 4.The selected sleep mode indicator will appear on the screen.



Mode	Sleep enabled
Cool.	Yes
Ventilation	
Dehumidifier	
Heating.	Yes
Car	

Sleep is disabled in Fan/Dry/Auto mode.



Note:
The main control screen may look slightly different depending on your air conditioner model.
Example as below:



Note:
Sleep mode is also disabled in Turbo/Sleep mode
for some air conditioner models.


THE Timer setting(on)

- 1. Tap the Timer button.
- 2. Tap + in the upper right corner of the Timer main screen.
- 3. Choose Time/Repeat/Off, then tap Save.
- 4. The timer (off) will appear on the main Timer screen.





Scroll up or down
to select the time

Tap Repeat > then tap the desired repeat
days or Once, then tap Confirm
Selection.





Tap Switch > then swipe the screen
to choose ON
and Confirm.




Timer Setting(off)

- 1.Tap the Timer button.
- 2.Tap + in the upper right corner of the Timer main screen.
- 3.Set repeat time/date/switch (ON)/temperature/mode/fan speed/airflow as desired and then tap Save.
- 4.The timer will appear on the main Timer screen.



Swipe up or down
down to select the time


Tap Repeat > then tap the desired repeat days or Once, then tap Confirm Selection.



Tap Switch > then swipe the screen to choose ON and Confirm.





Tap Temperature/Mode/Fan Speed/Air Flow > one at a time, then set as desired as mentioned in the previous chapter and tap Confirm Setting.



Air conditioner control


Timer Management

- 1.Change the timer setting:
Tap anywhere on the timer list bar except the switch bar to access the timer settings screen, change the setting, and then tap save.
- 2.Enable or disable the timer:
Tap the left side of the switch to disable the timer. Tap the right side of the switch to enable the timer.
- 3.Delete timer:
Swipe the Timer list bar from right to left until the Delete button appears, then tap Delete.



Swipe left to disable the timer.


Swipe right to enable the timer.




Air conditioner control

Other functions

1. Tap the More button to activate additional features if it appears on the screen.



Note:
Some models of air conditioners do not have the plus button.



Note: Appearance may vary, some icons will be hidden if your air conditioning does not have this function or is not enabled in the current mode.

2. Touch the "  "to turn on/off the internal LED display.
Screen



3. Touch the "  "to activate/deactivate the sound alarm while operating via Wi-Fi APP.
Beep

4. Touch the "  " button to activate the Anti-Mold function, if available on the screen.
Anti-mold

After the air conditioning is turned off, it will start to dry, reduce the residual humidity and prevent mold, when finished of the function, it will turn off automatically.

5. Touch the "  " button to enable/disable the healthy function, if available on the screen.
Health
Activates the antibacterial ionizer function. This function is only available for models with an ionizer generator.

6. Tap the "GEN Mode" button, if available on the screen. In this mode, you can choose one of three power levels. The air conditioner will maintain the appropriate power to save energy.



Air conditioner control



Other functions

7. Tap the "Electricity Monitor" button if it is available on the screen.

In this function, you can monitor the electricity consumption of the air conditioner.



Electricity Monitoring



You can tap this button to bring up the calendar, then select the date.

8.Touch the " " button, if available on the screen.



Self-cleaning

Check the details of the self-cleaning function in the User Manual.

9.Touch the "8" button°Heat" , if available on the screen. This feature helps keep the room temperature above 8°C . Check the details of function 8°C Heat on the User Manual.



8°C Heat

10. Tap the "Book" button, if available on the screen.

You can set the time, repeat the day, temperature, mode, fan speed, and airflow as desired, and then tap Save to activate the function. The air conditioner will automatically reach your settings at the scheduled time.



Reservation

Reservation

14	17
15	18
16	19
17	20
18	21

Repeat the setup **Monday... >**

Temperature 25°C

Mode Fantastic>

Fan speed Medium>

Precision airflow Up-down oscillation>

Save

Reservation



4:19 PM ☒

ON, Cool, Medium, Up-Down Oscillation 25°C...

After the reservation is set, the air conditioner will automatically reach the set requirements at the appointment time.

Other functions

11. Touch the "Self-diagnosis" button, if available on the screen. The air conditioner will automatically perform a diagnosis and display the error code and problem instructions, if possible.



12. Click the "  " if it is available on the screen.

Photosensitive

This function allows the air conditioner to automatically turn the display on/off based on the light intensity.

13. Click the "  " if it is available on the screen.

Soft Wind

In this function, the air conditioner will blow a soft stream of air through the micro holes on the deflector.


Device details and management

press

on the formatcontrol or touch "...of format dthe controls2,enter the device details screen.

Here you can get some useful information and share your device with other accounts. Please carefully review the following images and instructions.

Control Module 1




Control Module 2



Tap to change position of the device in another room

Please report any problems or suggestions to the APP administrator.



Tap tochange the device name

Check network status Tap to check network status

Tap to get instructions for connecting your Amazon Alexa or Google Assistant voice controller

Tap to share the device with another account

Tap to check the virtual ID/Wi-Fi name/IP address MAC Address/Time Zone/Single Wi-Fi Power


Check and update the firmware

Tap to remove the device and the device will be automatically restored once eliminated.

Device details and management


How to share devices with other accounts?

- 1. Tap "Device Sharing" and the Device Sharing screen appears.
- 2. Tap "Add Share".
- 3. Select your region and enter the account you want to share.
- 4. Tap "Done" and the account will appear in your sharing list.
- 5. Received sharing members need to long press on the home screen and swipe down to refresh the device list, the device will appear in the device list.



Accounting management

Setting up your account profile



Change your nickname of your account

Change name

Account one |

Cancel Save

Profile

Profile picture >


Nickname ***** >

Account Security >

Jet lag Universal >

Select an image for your account from local album

Select your time zone



Set a pattern password for APP launch

Account Security

Telephone number *****

Position Ita

Change login password >

Unlock model >

Change template password >

Deactivate Account >

Change your password
How to reset your password on page 7


Tap the switch to enable or disable Pattern password

Please be careful when deactivating your account. For Thatall data will be deleted.


Household management (family)

1.Touchin the upper left cornerfrom the home screen and select Home Management. Or tap Me and tap Home Management.

2.Tap one of the families in the list and access the Family Settings screen.



3. Set the family as the following indicators.



I notify

1. To improve service, technical updates to the APP are possible, so some entries in the manual may differ from the current appearance of the app. Please refer to the instructions in the app.
2. The smart air conditioner APP may be modified without notice for quality improvement and may also be discontinued depending on the circumstances of the manufacturing companies.
3. If the Wi-Fi signal strength is weak, the smart app may disconnect. So make sure the indoor unit is close to the wireless router.
4. The DHCP server function should be enabled for the wireless router.
5. Your internet connection may be failing due to a firewall issue. If this is the case, contact your internet service provider.
6. For smartphone system security and network settings, please ensure that the smart air conditioner APP is trusted.

troubleshooting

Description	Analysis of the cause
Conditioner cannot be configured successfully	1.Check that the SSID and password of the WLAN router connected to the mobile phone are correct; 2.Check if there are additional WLAN router settings as shown below. 1)Firewall from the router itself or from the PC 2)MAC address filtering 3)Hidden SSID 4)DHCP Server Restart the WLAN router, mobile device and air conditioner (WLAN module) and reconnect the Air conditioner in CF mode. Before restarting, make sure that no one is already connected to the same air conditioner.
The cell phone can't control conditioner	1.When the air conditioner (WLAN module) is restarted and the app displays Remove device, ignoring This confirmation will cause the mobile device to lose permission to control the air conditioner. StoYou will need to reconnect the air conditioner in CF mode. 2.In case of power failure, the mobile device will lose the air conditioner control permission. for 3 minutes after the power outage. (The notification will now appear on your mobile device.) If you cannot control the app (air conditioner) even after power is restored, you will need to Reconnect the air conditioner in CF mode.
The cell phone cannot find the air conditioner	1. Viewing the Air Conditioner app Device offline. Please check the following conditions. 1)The air conditioner has been reconfigured. 2)Air conditioning off. 3)Router without power. 4)The air conditioner cannot connect to the router. 5)The air conditioner cannot connect to the network via the router. 6)The mobile device cannot connect to the network. 2. After adding the device, it will disappear from the device list. Press and hold and swipe down to Refresh the device list. If there are no changes, close the app and start over.

Let's get start!

Operation guideline.Please take below simple guideline instruction as reference.

Operation Steps	Operation Items	New Account	Reinstall APP (registered before)
Step 1	Download and Install APP	YES	YES
Step 2	Activate APP	YES	YES
Step 3	Registration Account	YES	NO
Step 4	Login	YES	YES
Step 5	Add Device to Control	YES	Registered Device will remain.

Note If you registered the account and added device before, when you re-install the APP again and login, the added device will remain.

FCC Caution (FCC ID: 2AJCLTWAC-TYWFS)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The distance between user and device should be no less than 20cm.