



WIFI



CONTENUTI

Wi-Fi Module Specifications and Operation Guidelines	1
Download and install the application	2
Activate APP	3
Disc	4
Access	5
Add Device	7
Air conditioning control	9
Account Administration	12
Troubleshooting	30
Installing the Wi-Fi module (optional)	32

Wi-Fi Module Specifications and Operating Guidelines

1. Minimum specifications for a smartphone:

Android version 5.0 or later IOS version 9.0 or later

2. Basic parameters for the Wi-Fi module

Parameters	Details
Network frequency	2.400 - 2.4835 GHz
WLAN standards	IEEE 802.11 b/g/n (channels 1-14, channels 1-13 for EU/AU, channels 1-11 for US/CA)
Protocol stack support	IPv4/TCP/UDP/HTTPS/TLS/DNS
Security Support	WEP/WPA/WPA2/AES128
Network type support	STA/AP/STA+AP
Maximum RF Power	18.5 dBm
Frequency of blue teeth	2.402 - 2.480 GHz
Blue tooth RF power	9 dBm

3. Operational guidelines. Please take the simple guidelines instructions below as a reference.


operation Steps	operation Elements	New account	Reinstall the APP (recorded before)
Step 1	Download and Install the application	YES	YES
Step 2	Activate APP	YES	YES
Step 3	Registration Account	YES	NO
Step 4	Login	YES	YES
Step 5	Add device to control	YES	The registered device will remain.

Note

If you have registered the account and added the device before, when you reinstall the APP again and log in, the added device will remain.


Install the Wi-Fi module (optional)


1. Open the indoor unit panel.



2. Remove the USB Wi-Fi cover, follow the arrowD
Reserved USB slot on the chassis.

Hi**OU**Andi rt the USB Wi-Fi module in the





Download and install the app





SmartLife-SmartHome

For Android smartphones

Method 1: Scan the QR code with a browser scanner, download and install the app. Method 2: Open the Google Play Store on your smartphone and search for "Google Play Store".

"SmartLife-SmartHome", download and install the APP.



For iOS smartphones

Method 1: Scan the QR code and follow the prompts to enter "AppStore", download and install the APP.

Method 2: Open Apple's "AppStore" on your smartphone and search for "SmartLife-SmartHome", download and install the APP.





Please enable Storage/Location/Camera permissions for this APP during installation. Otherwise, it will have some problems during operation.

Activate APP


The first time you use the app, you will need to activate it.

1. Launch the "Smart Life" APP on your smartphone.



SmartLife-SmartHome

2. Method 1: Tap the "Scan" button and scan the QR code Activation Method 2: tap "or enter activation code" at the bottom of the screen,





Note Without the QR code or activation code, you can't activate the APP and use it, keep them safe.

Registration

- 1. If you don't have an account, tap the "Register" button.
- 2. Read the Privacy Policy and tap "I Accept."





Search for the country or swipe the screen up/down to find

- 3. Tap ">" and choose your country.
- 4. Enter your email address.
- 5. Tap the "Get Verification Code" button.

Resist

Enter your email address here

Afghanistan

Albania

Algeria

Angola

Argentina


Armenia

Australia

Registration

- 6. Enter the verification code you received by email.
- 7. Set the password with 6-20 characters including letters and numbers.
- 8. Tap "Done".






Login Login

- 1. Tap "Sign in with an existing account."
- 2. Enter your registered account and password.
- 3. Tap the "Login" button.






Login

The first time you use the APP, you need to Create Family:

- 4. Tap "Create Family".
- 5. Give the family a name.
- 6. Set the position.
- 7. Choose default rooms or add new rooms.
- 8. Tap "Done" and "Completed".



No


The app can open the map on your phone and you can set your location.

Login

You forgot your password

If you have forgotten your password or want to reset your password, please follow these steps:

- 1. Tap "Forgot Password".
- 2. Enter your account (email address) and tap the "Get Verification Code" button.
- 3. Enter the verification code received in your email.
- 4. Set your new password and tap the "Done" button.











There are 3 methods to add the device. Mode 1-CF


- 1. Turn on the indoor unit, no need to start the air conditioner.
- Click the "+" in the upper right corner of the Home screen or tap "Add Device" in the room that has no devices.
- 3. Tap the "Air Conditioner (BT+Wi-Fi)" logo.
- 4. Follow the prompts on the next screen to reset the Wi-Fi module, then Select "Confirm device reset" and tap "Next".
- Enter the Wi-Fi password that is the same as the one on your connected smartphone, then tap "Next".
- 6. You can see the percentage of the connection process,At the same time, "PP", "SA", "AP" light up in turn on the internal display.
 - "PP" means "Searching the router" "SA"
 means "connected to the router" "AP"
 means "connected to the server"


















Esistono 3 metodi per aggiungere il dispositivo.


Modalità 2-AP

- 1. Accendere l'unità interna, non è necessario avviare il condizionatore d'aria.
- Fai clic su "+" nell'angolo in alto a destra della schermata "Home" o tocca "Aggiungi dispositivo" nella stanza che non ha dispositivi.
- 3. Toccare il logo "Condizionatore d'aria "91%LX' Fi)".
- 4. Toc

 a nell'angolo in alto a destra e scegli "Modalità AP" quindi seguire i commenti sullo schermo per ripristinare il modulo LX' Fi, quindi selezionare "Conferma il ripristino del dispositivo" e toccare "Avanti".
- Inserisci la password del LX' Fi che è la stessa del tuo smartphone connesso, quindi tocca "Avanti".
- 6. Leggere attentamente le istruzioni e toccare "Connetti ora".
- 7. Nella schermata delle impostazioni di rete, seleziona "SmartLife-****" e tocca"< ".
- 8. Puoi vedere la percentuale del processo di connessione, allo stesso tempo "PP", "SA", "AP" si illumina a turno sul display interno.
 - "PP" significa "Ricerca nel router"
 - "SA" significa "connesso al router"
 - "AP" significa "connesso al server"







There are 3 methods to add the device.

Mode 3-Bluetooth

- 1. Turn on the indoor unit, no need to start the air conditioner.
- 2.Click "+" in the upper right corner of the "Home" screen or tap
- "Add device" to the room that has no devices.
- 3.Tap the "Air Conditioner (BT+Wi-Fi)" logo.
- 4. Make sure your smartphone's blue tooth is available.
- 5. Tap fn the top right corner and choose "Bluetooth"


 Then follow the on-screen prompts to reset the Wi-Fi module, then select "Confirm that the blue tooth has been reset" and tap "Next".
- 6.Select one of the found devices and tap "+"
- 7.Enter the Wi-Fi password that is the same as the one of your connected smartphone, then tap "Next".
- 8. You can see the percentage of the connection process,at the same time "PP","SA","AP" lights up in turn on the internal display.

"PP" means "Searching the router" "SA"

means "connected to the router" "AP"

means "connected to the server"






Air conditioner control

The device control screen will appear automatically after adding the device.

The device control screen will be displayed manually by tapping the device name on the home screen.



Note:


There are two different control methods based on different software or firmware versions of the Wi-Fi module. Please read the manual carefully based on the actual control interface.

Sample 2 Sample 2 (b) Set temperature 公 社 Fan Function Timer



Control Module 1

The main control interface



Air conditioner control

Control Module 1-Mode Setting

- 1. Tap Mode to bring up the Mode screen.
- 2. Select one of the Feel/Cool/Heat/Dry/Fan modes.
- Touch anywhere around the set temperature to cancel the mode setting.



Control Module 1-Function Setting

- 1. Tap Function to bring up the Function screen.
- 2. Select one of the Sleep/Turbo/ECO functions.
- Select UP-DOWN/LEFT-RIGHT for swing automatic with UP-DOWN/LEFT-RIGHT direction.
- 4. Touch anywhere around the set temperature to cancel the function setting.



Control Module1-Select fan speed


- 1. Tap Fan to bring up the Fan screen.
- 2. Select one of the fan speeds High/Medium/Low/Auto.
- Touch anywhere around the set temperature to cancel the selection.



Control Module 1-Add Timer


- 1. Tap Timer to bring up the Add Timer screen.
- 2. Tap Add Timer.





Control Module 1-Add Timer

- 3. Select the time, select the repeat days and Timer on/off.
- 4. Select Mode/Fan Speed/Function and select the setting temperature for Timer on.
- 5. Tap Save to add the timer.




<

<

Control Module 1 - Timer Management

- 1. Tap the timer bar to edit the timer as the process of adding the timer.
- 2. Click the switch to enable or disable the timer.
- 3. Press and hold the timer bar for about 3 seconds and the Remove Timer screen will appear, tap CONFIRM and remove the timer.




Control Module 2

The main control interface Return to the Suggestions Home screen Device name Current mode Increase the Decrease the temperature setting temperature setting Different background for different modes: Cold/Heat/Dry/Fan/Auto Selected functions indicator **Function buttons** On/Off Note:It may look slightly different depending on the air conditioner model. For example, see Mode Precision ON OFF below: Air flow Echo Timer Sleep 00 Turbo Echo

Form2 Control - Setup Mode

- 1. Tap the Mode button.
- There are 5 modes in the Mode screen, tap one button to set the air conditioner operating mode.
- 3. Tap the X button to return to the main control screen.
- 4. The mode and wallpaper will change on the screen.





Note:Please read the details of each mode in the user manual for more comfortable control.

Control Module 2 - Fan Speed Selection

- 1. Tap the Fan Speed button.
- 2. Select the desired fan speed and tap it.
- 3. Tap the X button to return to the main control screen.
- 4. The selected fan speed indicator will appear on the screen.





Mode	Fan speed
Cold	All speeds
Fan	All speeds
Dry	
Heat	All speeds
Car	All speeds

Note:

The fan speed can be set to Dry mode.

Note: The fan speed screen may look slightly different,

Depending on the air conditioner model. Example:




Air conditioner control


Control Module 2 - Air Flow Control

- 1. Tap the Precision Airflow button or the Oscillating Airflow button.
- 2. Select the desired airflow and tap it.
- 3. Tap the X button to return to the main control screen.
- 4. The selected airflow indicator will appear on the screen.

Note: For some models without automatic left-to-right wind, if you activate it, you will hear a beep, but no action.







Note:The main control screen and the airflow screen may appear slightly different depending on the air conditioner model. Examples are as follows:





Control form2-ECO function

- 1. For Eco function, just touch the button to activate the function, the button will light up and the indicator will appear on the screen.
- 2. Tap again to disable the function.
- 3. Temperature controlled for some models of air conditioners: in

Cooling mode, the new set temperature will be In heating mode, the new set temperature will be

≥ 26°C. ≤ 25°C.





Mode	ECO enabled
Cold	Yes
Fan	
Dry	
Heat	Yes
Car	

ECO is disabled in Fan/Dry/Auto mode.

Note:The main control screen and ECO control method may appear slightly different depending on the air conditioner model. Example below:



Note:

ECO is also disabled in Turbo/Sleep mode for some air conditioner models.

Control Module 2 - Sleep Function

- 1. Tap the Sleep button.
- 2. Choose the desired sleep mode and tap it.
- 3. Tap the X button to return to the main control screen.
- 4. The selected sleep mode indicator will appear on the screen.





Modality	Sleep enabled
Cold	Yes
Fan	
Dry	
Heat	Yes
Car	

Sleep is disabled in Fan/Dry/Auto mode.

Note:

The main control screen may look slightly different depending on the air conditioner model. For example, see the following:





Note:

Sleep mode is also disabled in Turbo/ Sleep for some air conditioner models.


Air conditioner control

Control form2-Set Timer(on)

- 1. Tap the Timer button.
- 2. Tap + in the upper right corner of the Timer main screen.
- 3. Choose Now/Repeat/Off, then tap Save.
- 4. The timer (off) will appear on the main Timer screen.








Tap Repeat > then tap the desired repeat days or Once, then tap Confirm Selection.






ON


Air conditioner control

Control Module 2-Timer Setting(off)

- 1. Tap the Timer button.
- 2. Tap + in the upper right corner of the Timer main screen.
- Set time/date repeat/switch (ON)/temperature/mode/ fan speed/airflow as desired and then tap Save.
- 4. The timer will appear on the main Timer screen.







Tap Repeat > then tap the desired repeat days or Once, then tap Confirm Selection.



9:29 PM
OTF. day of the week

4:30 AM
wormood

4:19 PM
ON, cold, medium, oscillating up and down 25 °C, M...

Touch Temperature/Mode/Fan Speed/ -Airflow > one by one, then set as desired as mentioned in the previous chapter

and tap Confirm Setting.

Control Module 2 - Timer Management

1.Change the timer setting:

Tap anywhere on the timer list bar except the switch bar to access the timer settings screen, change the setting, and then tap save.


2. Enable or disable the timer:

Tap the left side of the switch to disable the timer. Tap the right side of the switch to enable the timer.

3. Delete the timer:


Swipe the Timer list bar from right to left until the Delete button appears, then tap Delete.





Swipe left to disable the timer.

Swipe right to enable the timer.



Control Module 2 - Other functions

1. Tap the More button to activate additional features if it appears on the screen.



Note:

Some air conditioner models do not are available't have the plus button.



Note: Appearance may vary, some icons will be hidden if your air conditioning does not have this function or is not enabled in the current mode.

- 2. Touch" (to turn on/off the internal LED display.
- 3. Touch" ((1)) "to turn the buzzer on/off during operation via Wi-Fi APP.
- 4. Tap the " (button to activate the Anti-Mold function, if available on the screen.

Anti-mold


After the air conditioning is turned off, it will start to dry, reduce the residual humidity and prevent the formation of mold, at the end of the function, it will automatically turn off.

5. Tap the " button to enable/disable the healthy function, if available on the screen.

Activates the antibacterial ionizer function. This function is only available for models with an ionizer generator.

6. Tap the " button, if available on the screen.

In this mode, you can choose one of three power levels. The air conditioner will maintain the appropriate power to save energy.



Control Module 2 - Other functions

7. Tap the "Electricity Monitor" button if it is available on the screen.

In this function, you can monitor the electricity consumption of the air conditioner.







You can tap this button to bring up the calendar, then select the date.

8. Tap the "



" button, if available on the screen.

Self-Cleaning

Check the details of the self-cleaning function in the User Manual.

9. Tap the "



" button, if available on the screen.

8℃ Heat

This function helps to keep the room temperature above 8 . Check the details of the 8 Heat function in the User Manual.

 $^{\circ}$

10. Tap the "Booking" button, if available on the screen.

You can set the time, repeat day, temperature, mode, fan speed, airflow as you like.

want and then tap Save to activate the feature.

The air conditioner will automatically reach your settings at the appointment time.







Control Module 2 - Other functions

11. Tap the "Self-diagnosis" button, if available on the screen.

The air conditioner will automatically diagnose and display the error code and instructions related to the problem, if possible.





12. Tap the "



" if it is available on the screen.

This function allows the air conditioner to automatically turn the display on/off based on the light intensity.

13. Tap the "



" if it is available on the screen.

In this function, the air conditioner will blow a soft stream of air through the micro holes on the deflector.


Device details and management

Faucet on control form1 or tap ... on control form2, enter the device details screen.

Here you can get some useful information and share your device with other accounts. Please carefully review the following images and instructions.








Device details and management

How to share devices with other accounts?


- 1. Tap "Device Sharing" and the Device Sharing screen appears.
- 2. Tap "Add Share".
- 3. Select the region and enter the account you want to share.
- 4. Tap "Done", the account will appear in your sharing list.
- Received sharing members need to press and hold on the home screen and swipe to the Click below to refresh the device list, the device will appear in the device list.












Accounting management

Setting up your account profile









Accounting management

Household management (family)

- 1. Tap the name of your home in the upper left corner of the home screen and select Home Management. Or tap Me and tap Home Management.
- 2. Tap one of the families in the family list and access the Family Settings screen.



3. Set the family as the following indicators.



I notify

- 1. Due to technical updates, actual items may differ from the manual. Please refer to the actual product and APP.
- The smart air conditioner APP can be changed without notice for quality improvement, and can also be eliminated depending on the circumstances of the manufacturing companies.
- If the Wi-Fi signal strength is weak, the smart app may disconnect. So make sure the indoor unit is turned on. is close to the wireless router.
- 4. The DHCP server function should be enabled for the wireless router.
- Your Internet connection may be failing due to a firewall issue. In this case, contact your ISP. Internet services.
- 6. For smartphone system security and network settings, please ensure that the smart air conditioner APP is trusted.

troubleshooting

Description	Analysis of the cause
Conditioner cannot be configured successfully	1. Check whether the SSID and password of the WLAN router connected to your mobile phone are correct; 2. Check if there are additional WLAN router settings as shown below. 1) Firewall from the router itself or from the PC 2) MAC address filtering 3) Hidden SSID 4) DHCP Server Restart the WLAN router, mobile device and air conditioner (WLAN module) and reconnect the Air conditioner in CF mode. Before restarting, make sure no one is already connected to the same conditioner.
The cell phone can't control conditioner	1. When the air conditioner (WLAN module) is restarted and the app displays Remove Device, ignoring this confirmation will cause the mobile device to lose permission to control the air conditioner. You will need to reconnect the air conditioner in CF mode. 2. In the event of a power outage, your mobile device will lose control of the air conditioner for 3 minutes after the power outage. (A notification will now appear on your mobile device.) If you can't control the app (air conditioner) even after power is restored, it will be You need to reconnect the air conditioner in CF mode.
The cell phone cannot find the air conditioner	1. Viewing the Smart Life App Air Conditioner Device offline. Please check the following conditions. 1) The air conditioner has been reconfigured. 2) Air conditioning off. 3) Router without power. 4) The air conditioner cannot connect to the router. 5) The air conditioner cannot connect to the network via the router. 6) The mobile device cannot connect to the network. 2. After adding the device, it disappears from the device list. Press and hold and swipe down to refresh the device list. If there are no changes, close the app and start over.



